Bodywork Exterior Pass ✓Fail X

Entrance Door Operation
Hinges/locks Lubrication
Door Seals
Check all Grab Handles
Check all Trims & Inserts
Check all Seals & Sealant
Check Lockers/Locks/Hinges & Lubricate
Check Condition of Windows

Gas (Fridge not serviced unless requested)

Check date & condition of felxible hose
Carry out gas leak test
LPG Warning sticker on gas bottle locker?
Check security of gas bottle
Check dispersal hose at appliance locations
Fridge light & test for cooling
Cooking appliances light & test
Space heater light & test
Water heater light & test

Water System

Check water heater drain plug
Change Charcoal water filter if fitted
Check operation of water pump
Check operation of all taps (clean grit traps)
Check toilet blade & flush operation
Waste system check for leaks
Check pressure switch & adjust if necessary
Check operation of shower head (clean grit trap)

Interior Checks

Damp Meter check (see separate report sheet)
Check floor for delamination
Check all skylights & lubricate
Check blinds & flyscreens
Check all cupboard stays, catches & hinges
Check all door/bed lockers/hinges/catches
Check operation of all window stays & catches

Fire Warning Sytems

Check operation of smoke alarm and battery
check expiry date of extinguisher

Electrical Systems 240v Pass ✓Fail X

Check operation of inlet plug
Check operation of RCD and MCB's
Test all 13 amp sockets
Check wiring circuits & fuses
Check mains lighting
Check 240v operation of fridge
Check 240v operation of water heater
Check 240v operation of space heater
Check operation of air conditioning
Check operation of battery charger

Electrical Systems 12 Volts

Check 12n & 12s plugs & cables
Check operation of road lights
Check awning light operation
Check and test condition of leisure battery
Check ventilation in battery compartment
Check operation of all 12v interior lights
Check operation of all 12v sockets
Check 12v Status aerial for operation
Check 12v operation of fridge
Check blown air operation
Check operation of roof light fans (if fitted)

Chassis and Running Gear

Check coupling head, lubricate if necessary
Check pads on ball acting stabiliser (if fitted)
Check condition of breakaway cable & clip
Check Jockey wheel & lubricate
Lubricate overun piston with grease gun
Check condition of jacking points
Check operation of spare wheel carrier - lubricate
Check condition of tyres & inflate to correct pressure
Check and tighten chassis assembly nuts/bolts **96NM**
Remove wheels/drum assemblies - remove dust
Check bearings brakeshoes & seals
Replace split pin or one shot nuts
Torque one shot nuts if fitted to **280NM**
Adjust brakes at drums
Replace wheels and torque check nuts and bolts steel **96NM** Alloy **110NM**
Check handbrake operation & adjust if necessary
Fix Serviced by sticker to A frame nearside